



Disney

10775



WARNING: CHOKING HAZARD.
Toy contains small parts and a small ball.
Not for children under 3 years.

Check for compatibility
Kompatibilität prüfen
Vérifier la compatibilité
Controlla la compatibilità
Comprueba tu compatibilidad
Verificar a compatibilidade
Ellenőrizd a kompatibilitást
Pārbaudīt saderību
检查兼容性

LEGO.com/devicecheck



乐高®拼搭指引



LEGO® Building Instructions



Download on the
App Store



GET IT ON
Google Play



腾讯应用宝
安卓应用商店



Apple and the Apple logo are trademarks of Apple Inc.
Google Play and the Google Play logo are trademarks of Google LLC.
Tencent and the Tencent logo are trademarks of Tencent Inc.


**AVERTISSEMENT :**


RISQUE D'ÉTOUFFEMENT. Le jouet contient des petites pièces ainsi qu'une petite boule. Il ne convient pas aux enfants de moins de 3 ans.




**ADVERTENCIA:**


PELIGRO DE ASFIXIA.


Juguete que contiene partes pequeñas y una pelota pequeña. No recomendado para niños menores de 3 años.






































































































































































































1x
6313647



1x
6254176



1x
6063275



1x
4547489



1x
6143555



1x
6143604



2x
4113261



1x
6117940

70



1x
6143595



1x
6349205




1x
6349208



2x
4141607



1x
6031098



4x
6256922



2x
300101



1x
6342625



3x
4655900



1x
4124456



1x
4109995



1x
6343565



2x
306221



1x
6096955



2x
6029946



2x
4121934



1x
407921



4x
329821



2x
6083618



2x
6334053



1x
6054438



1x
4651524



1x
9341



1x
4560180



3x
4525464



1x
6227901



1x
6271886



1x
249626



1x
6336633



2x
6336638



2x
4619323




1x
6092586



3x
6116259



2x
6270003



1x
6345794



1x
4119479



1x
6238674



2x
6310290


2x
6250319


2x
6038459


2x
6013530


2x
6013530


2x
6167465


1x
6269007


2x
4666352


2x
6212081


2x
6343886



2x
6342613


2x
4520612


4x
4224243


1x
6172808


3x
4211149


1x
4211151


3x
4211201


2x
4221590


1x
6270119


1x
6103249


1x
4529241



1x
4211383


1x
6321770


1x
4226995



1x
6343889



2x
6109684



1x
4211394


1x
4211795


1x
6172316


1x
4225715


1x
6352696


1x
6336632



: 00800 5346 5555
: 1-800-422-5346



Customer Service
Kundenservice
Service Consommateurs
Servicio Al Consumidor

LEGO.com/service or dial



Disney

 ©Disney
www.disney.com

LEGO and the LEGO logo are trademarks of the/sont des marques de commerce du/son marcas registradas de LEGO Group.
©2021 The LEGO Group.
6370278



10776



10774



10772

10775



10773



4+

Disney
MICKEY
AND FRIENDS

