






CREATOR




31071



LEGO.com/creator




1



2




2






3




4






1x

5



1x

6






2x



1x

7





2x




1x

8






9




10





1x

11




1x



1x


12






1x

13



14






1x

15



1x


16





1x

17




1x



1x


18







1x

19





20






21






22



23





1x




1x



2x

24


1



2



3





1x




2x





1x

25






1x



26






27







28





2x


29






1x

30



2x

31





32

