



40201



WARNING: CHOKING HAZARD.
Toy contains small parts and a small ball.
Not for children under 3 years.

1



2



3



4






1x



1x

1



1x



1x

2



AVERTISSEMENT : RISQUE D'ÉTOUFFEMENT.

Le jouet contient des petites pièces ainsi qu'une petite boule.
Il ne convient pas aux enfants de moins de 3 ans.



ADVERTENCIA: PELIGRO DE ASFIXIA.

Juguete que contiene partes pequeñas y una pelota pequeña.
No recomendado para niños menores de 3 años.



1x



2x

3





4





1x

4






5






6



6



7







2x



2x

8




1x



2x


9






2x

10





1x

11






12



13









1x





2x

14






15






1x


16




2x

17






18



19






1x




1x

20



1x


21






3x

22



1x

23







1x



1x

24






2x





1x


25





2x


26






27






28



29






1x





1x

30



1x

31






1x



2x

32




2x



1x

33





2x

34




2x



2x

35






1x



1x

36



1x



1x



2x

37





1x



2x

38



1x



2x

39







2x



2x

40





1x



1x

41






1x




1x


42





2x


43






44





45



1






2




3





4






46





47






48


1




2




3



4








1x

49





Customer Service

Kundenservice

Service Consommateurs

Servicio Al Consumidor

LEGO.com/service or dial



: 00800 5346 5555

: 1-800-422-5346

