

The LEGO logo is displayed in its characteristic white font on a red rectangular background.

41060




WARNING: CHOKING HAZARD.
Small parts. Not for children under 3 years.



[LEGO.com / disneyprincess](http://LEGO.com/disneyprincess)


⚠ **AVERTISSEMENT : RISQUE D'ÉTOUFFEMENT.**
Contient des petites pièces. Ne convient pas aux enfants
de moins de 3 ans.

⚠ **ADVERTENCIA: PELIGRO DE ASFIXIA.**
No recomendado para niños menores de 3 años.
Contiene piezas pequeñas.







1




2



3





4



5




6




1



2



3



7



8



9



10



11






1




2




3



4





5



6




7



8



9






1



2



3



4



5




6







1



2




3






1





2





3



1



2



4





5



6



4



5




6




7




8




9




10



11




12



13



14







Disney
FROZEN

Disney
FAIRY TALES

Disney
FROZEN

41061

41062

41055

41054

41060

41063



Customer Service

Kundenservice

Service Consommateurs

Servicio Al Consumidor

LEGO.com/service or dial



: 00800 5346 5555

: 1-800-422-5346