

LEGO

Mixels

41532

BURNARD




CN
CARTOON NETWORK



LEGO.com


1



2



3



1




2



3



4



1




2



3




5




4


6




7




8




9






1



2



3




4




5




6



7




8



9




10



11




12



13



14





1



2



3




4



5



15





1



2



3




4



5



16



17





2x

4547649



1x

4121934



2x

306921



1x

4226876



1x

6053077



1x

4244369



2x

4224792



2x

6029946



1x

302221



1x

6089576



2x

302326



1x

6056842



1x

6046381



2x

6065839



4x

4524644



1x

6023770



1x

6016172



4x

4531415



2x

6056225



2x

366021



2x

4597713



2x

6102786



1x

4613759



1x

6092597



Customer Service

Kundenservice

Service Consommateurs

Servicio Al Consumidor

LEGO.com/service or dial



00800 5346 5555 :



1-800-422-5346 :



1x

487121



1x

4140303



2x

4568385



1x

4143372



1x

4539060



1x

6071222



2x

6043656



**MELTUS
41530**



**FLAMZER
41531**



**BURNARD
41532**



**INFERNITES
MAX!**



LEGO.com/mixels





Mixels



LEGO.com/mixels





Mixels

CN
CARTOON NETWORK