




CITY


4643



1




2







+




1




2







3




4




5




6




7




8




9




10




11




12




13




14




15




16




17



18



19







1




2



3



4




5




6




20




21




22




23




24





25





CITY



7279



7285



7286



7287



7288



7498



www.LEGOclub.com



LEGO® Club Email



LEGO® Club Magazine

 www.LEGO.com

SIGN UP ONLINE!

www.LEGOclub.com

LEGO and the LEGO logo are trademarks of the LEGO Group. © 2011 The LEGO Group.4631453



00800 5346 5555*



1-866-534-6258 • 1-877-518-5346

US & Canada only

Canada seulement

- * Freephone. Mobile charges may apply.
- * Numéro sans frais. Des frais peuvent s'appliquer avec les téléphones cellulaires.
- * Gebührenfrei. Kosten für Anrufe aus Mobilfunknetzen können abweichen.
- * Gratis telefoonnummer vanaf vaste lijn.
- * Det er et gratis nummer, når du ringer fra fasttelefon.
- * Det är gratis, när du ringer från en fast telefon.
- * Numéro sans frais. Des frais peuvent s'appliquer avec les téléphones portables.